

# Adhesive matrix based on parquet formats

	MS 40	MS 35	Quantum	F5*	Adhesive Trowel Type TKB
Unicopark			●		B12–B13
Silverline Edition   Villapark   Studiopark		●	●		B8–B10
Spinpark			●		B8–B10
Casapark		●	●		B12–B13
Formpark 780 & 520   Formpark Mini 570 & 380   Formpark Quadrato   Formpark Rombico		●	●		B8–B10
Trendpark 1390 & 1450   Cleverpark		●	●		B8–B10
Vectorpark			●		B8–B10
Unopark   Solopark   Monopark		●	●	●	B6
Multipark 9.5 & 10		●	●		B8–B10
Solid parquet   On-edge		● <sup>1</sup>	● <sup>1</sup>	●	B6
Prepark   Prepark Comfort		●	●	●	B6
Cleverpark Silente**	●		●		B8–B10
Triopark		●	●		B12–B13

## Note

- \* when applying F5 on calcium sulphate flowing screed, apply first Bona D515
- \*\* Please use MS40 if Cradle to Cradle® certification is desired.
- <sup>1</sup> Plies to oiled surfaces, for lacquered surfaces only use Bona lacquer.

## General Information

- this table is applicable for examined, suitable subfloors for parquet such as cement-, calcium sulphate- and calcium sulphate flowing screed, chipboards and fibreboards.
- all types of glue listed in this overview are suitable for underfloor heating
- for any further information please address to your Bauwerk contact person